




CAD drawing data catalog
is available.



KOGANEI

VALVES GENERAL CATALOG

SOLENOID VALVES 110 SERIES INDEX

SOLENOID VALVES 110 SERIES

Features	293
Basic Models and Configuration	295
110 Series	
Specifications	297
Cylinder Operating Speed and Flow Rate	299
Tandem Solenoid Valve Order Codes	300
Solenoid Valve, Air-piloted Valve Order Codes	301
Manifold Order Codes	302
Operating Principles and Symbols, Major Parts and Materials	303
Dimensions of Solenoid Valve	304
Dimensions of Manifold	309
Made to Order	315
Plug Connector	
DIN Connector	
LED Indicator	
Built-in Interface Unit	
Air-piloted Valves 110 Series	
Handling Instructions and Precautions	321
PC Board Manifold 110 Series	
Specifications	323
Order Codes	324
Dimensions	325
Handling Instructions and Precautions	328



Caution

Before use, be sure to read the "Safety Precautions" on p. 31.

Reliability & Versatile Applications

SOLENOID VALVES 110 SERIES

The 110 series Solenoid Valves, which achieve highly reliable, powerful, and low current basic performance in a compact, thin body, offer a simple and flexible standard type, and a full-option type with advanced maintenance features, to become still more user-friendly.

Standard type

Its clean lines emphasize basic performance, for low-cost and versatile applications.

- With a varistor for the AC type, and a flywheel diode for the DC type, the solenoid is equipped with excellent surge suppression measures.
- A manual override (non-locking type) is standard equipment and offers easy adjustment during assembly and maintenance. A fingertip-operable protruding-type manual override (locking type) is also available as an option.



Full-option type


Greatly Improves piping and wiring work efficiency, for excellent applications in assembly, adjustment, and maintenance.

- Equipped with an easy-to-handle plug connector for fast wiring installation and removal. Available in a straight type and L type, both are equipped with LED indicators for easy confirmation of operations.
- Built-in quick fittings offer one-touch simple tube installation and removal. Moreover, an effective area of 4.0mm² [Cv: 0.22] enables even more powerful applications.



F type manifold


Direct piping type valves can be mounted directly on this manifold. An FE type manifold enabling collected pilot exhaust through its PR port is also available.




AJ type manifold

Combines all ports into a manifold base. Quick fittings are built into the delivery ports (4(A), 2(B)), allowing easy assembly and maintenance in a confined space.

- The common terminal pre-wired plug connector type frees technicians from tedious common terminal wiring work. Crossover wires are used to connect the common terminals, so that a single common wire is sufficient even for a manifold with many stations.
- Piping to the pilot exhaust ports is also possible to keep the control box interior and working environment from becoming contaminated. The built-in check mechanism prevents exhaust interference.




Twin Solenoid Valve



Ensures the functions of the conventional double solenoid type, but in a much shorter length, while simple wiring enables correct connections with a sequencer. Moreover, it is capable of being installed on a conventional manifold to occupy space for two stations.


SOLENOID VALVES 110 SERIES

Tandem Solenoid Valve




Retains the performance specifications of the 110 series while realizing a two-unit combination solenoid in the space of a single station. Achieves a compact outer appearance for the manifold and still more space savings.

PC Board Manifold 110 Series



Secures ease of use by using a printed circuit board with a connector for quick wiring connection to control devices. This simplified wiring method greatly reduces wiring work and the need for tools.

Single unit

	2-, 3-port	5-port
Direct piping	Normally closed (NC) Normally open (NO)   111E1 111E1-11 (□110E1)^{Note 1} (□110E1-11)^{Note 1}	2-position Single solenoid Double solenoid   110-4E1 110-4E2 (□110-4KE2)^{Note 2} 3-position Closed center Exhaust center Pressure center    113-4E2 113-4E2-13 113-4E2-14 (□113-4KE2)^{Note 2} (□113-4KE2-13)^{Note 2} (□113-4KE2-14)^{Note 2}
Sub-base piping	Normally closed (NC) Normally open (NO)   A111E1-25 A111E1-11-25	2-position Single solenoid Double solenoid Closed center Exhaust center Pressure center      A110-4E1-25 A110-4E2-25 A113-4E2-25 A113-4E2-13-25 A113-4E2-14-25 2-position (tandem solenoid) 3-position (tandem solenoid) Double solenoid Closed center Exhaust center Pressure center     A110-4ME2 A113-4ME2 A113-4ME2-13 A113-4ME2-14


Notes: 1. 110E1 and A110E1 are dedicated valves for manifolds with combination mounting of 2-, 3-, 5-port valves. They cannot be used as single units. For single unit applications, use 111E1 or A111E1-25.

2. They are dedicated twin solenoid valves for manifolds with combination mounting of 2-, 3-, 5-port valves. They cannot be used as single units.


Manifold

Small sized manifold for 2-, 3-port valves


111M□F—F type (1(P), 3(R)) manifold



111M□A—A type (all ports) manifold




111M□AJ—AJ type (all ports, with quick fittings) manifold




Manifold for combination mounting of 2-, 3-, 5-port valves


110M□F—F type (1(P), 3(R2), 5(R1)) manifold




110M□FE^{Note}—FE type (1(P), 3(R2), 5(R1), PR) manifold



110M□A—A type (all ports) manifold



110M□AJ—AJ type (all ports, with quick fittings) manifold



SOLENOID VALVES

110 SERIES

Basic Models and Valve Functions

Basic model Item	Direct piping, F, FE type manifolds	111E1 (110E1 ^{Note})	110-4E1 110-4E2	110-4KE2 ^{Note}	113-4E2	113-4KE2
	Sub-base piping, A, AJ type manifolds	A111E1 (A110E1 ^{Note})	A110-4E1 A110-4E2 A110-4ME2	A110-4KE2 ^{Note}	A113-4E2 A113-4ME2	A113-4KE2
Number of positions		2 positions			3 positions	
Number of ports		2, 3 ports	5 ports			
Valve function		Normally closed (NC, standard) or Normally open (NO, optional)	Single solenoid, Double solenoid or Tandem solenoid	Twin solenoid	Closed center (standard), Exhaust center (optional), Pressure center (optional) or Tandem solenoid	Closed center (standard), Exhaust center (optional), Pressure center (optional) or Twin solenoid

Remark : For optional specifications and order codes, see p.300~302.

Note : The 110E1, A110E1, 110-4KE2, and A110-4KE2 are dedicated valves for manifolds with combination mounting of 2-, 3-, 5-port valves. They cannot be used as single units. When using 2-,3-port valves as single units, use 111E1 or A111E1-25.

Specifications

Basic model Item	Direct piping, F, FE type manifolds	111E1 (110E1)	110-4E1 110-4E2	110-4KE2		113-4E2	113-4KE2	
	Sub-base piping, A, AJ type manifolds	A111E1 (A110E1)	A110-4E1 A110-4E2	A110-4KE2	A110-4ME2	A113-4E2	A113-4KE2	A113-4ME2
Media	Air							
Operation type	Internal pilot type							
Effective area [Cv] ^{Note 1} mm ²	4.2 [0.23]				4.0 [0.22]	3.8 [0.21]		3.6 [0.2]
Port size ^{Note 2}	M5×0.8							
Lubrication	Not required							
Operating pressure range MPa [kgf/cm ²] [psi.]	0.15~0.7 [1.5~7.1] [22~102]							
Proof pressure MPa [kgf/cm ²] [psi.]	1.05 [10.7] [152]							
Response time ^{Note 3} ms	DC12V, DC24V	15/25 or below	15/25 [20] or below		15 or below	15/30 or below		
	AC100V, AC200V	15/15 or below	15/15 [15] or below		—	15/20 or below		—
ON/OFF								
Maximum operating frequency Hz	5							
Minimum time to energize for self holding ms	—		50(□110-4E2)	50		—		
Operating temperature range (atmosphere and media) °C [°F]	5~50 [41~122]							
Shock resistance m/s ² {G}	1373.0 {140.0} (Axial direction 294.2 {30.0})					294.2 {30.0}		
Mounting direction	Any							

Notes : 1. For details, see the effective area on p.298.

2. For details, see the port size on p.298.

3. Values when air pressure is 0.5MPa {5.1kgf/cm²} [73psi.]. Values in brackets [] for 110-4E2, 110-4KE2, and 110-4ME2 are when switching from the opposite position, while the values for 113-4E2, 113-4KE2, and A113-4ME2 are those of the closed center valve, when switching from the neutral position.

Solenoid Specifications

Item	Rated voltage	DC12V	DC24V	AC100V	AC200V	DC24V (Tandem solenoid)
Type		Flywheel diode incorporated for surge suppression		Shading type		Built-in surge absorption transistor
Operating voltage range V		10.8~13.2 (12±10%)	21.6~26.4 (24±10%)	90~132 (100±32%)	180~264 (200±32%)	21.6~26.4 (24±10%)
Current (when rated voltage is applied)	Frequency Hz	—	—	50	60	—
	Starting mA (r.m.s)	—	—	36	32	—
	Energizing mA (r.m.s)	130 (1.6W) (140 (1.7W) with LED indicator)	65 (1.6W) (75 (1.8W) with LED indicator)	24	20	50 (1.2W)
Allowable leakage current mA		8	4	4	2	2
Insulation resistance MΩ		Over 100				
Wiring type and lead wire length	Standard	Grommet type: 300mm [11.8in.]				Plug connector type: 300mm [11.8in.]
	Optional	Plug connector type: 300mm [11.8in.] Note: See made to order on p.315~316.				—
Color of lead wire		Brown (+) Black (—)	Red (+) Black (—)	Yellow	White	Red (SA), Black (COM) White (SB)
Color of LED indicator		Red		Yellow	Green	Red
Surge suppression (as standard)		Flywheel diode		Varistor		Surge absorption transistor

Effective Area [Cv]

mm² [Cv]

Basic model	Standard (Single valve)	Built-in quick fittings	Remarks
111E1 ^{Note} (110E1) 110-4E1 110-4E2 110-4KE2	4.2 [0.23]	-J4□ : 3.6 [0.20] -J6□ : 4.0 [0.22]	● When attaching TS4-M5 to the 1(P), 4(A), 2(B) ports, the value is 1.8 [0.10]. ● On the F type manifold, attaching TS4-M5 to the 4(A), 2(B) ports gives the value 2.1 [0.12]. ● When large flow rates are required, we recommend the φ 6 built-in quick fitting.
113-4E2 113-4KE2	3.8 [0.21]	-J4□ : 3.4 [0.19] -J6□ : 3.6 [0.20]	
A111E1 ^{Note} (A110E1) A110-4E1 A110-4E2 A110-4KE2 A110-4ME2	4.0 [0.22]	-J4□ : 3.6 [0.20] -J6□ : 4.0 [0.22]	● When mounting on a sub-base or manifold. ● Attaching TS4-01 to the 1(P), 4(A), 2(B) ports on the sub-base gives the value 3.2 [0.18].
A113-4E2 A113-4KE2 A113-4ME2	3.6 [0.20]	3.6 [0.20]	

Note: The delivery port is the 2(A) for 111E1, A111E1.

Solenoid Valve Port Size

Basic model	Port specification		Port size
111E1 ^{Note1} (110E1 ^{Note2})	Standard	Female thread	M5×0.8
	Optional	-J41	Quick fitting for φ 4, for 2(A) (4(A)) port only
		-J42	Quick fitting for φ 4, for 1(P), 2(A) ports
		-J61	Quick fitting for φ 6, for 2(A) (4(A)) port only
		-J62	Quick fitting for φ 6, for 1(P), 2(A) ports
110-4E1 110-4E2 110-4KE2 113-4E2 113-4KE2	Standard	Female thread	M5×0.8
	Optional	-J42	Quick fitting for φ 4, for 4(A), 2(B) ports only
		-J43 ^{Note3}	Quick fitting for φ 4, for 1(P), 4(A), 2(B) ports
		-J62	Quick fitting for φ 6, for 4(A), 2(B) ports only
		-J43 ^{Note3}	Quick fitting for φ 6, for 1(P), 4(A), 2(B) ports
A111E1-25 ^{Note1} A110-4E1-25 A110-4E2-25 A113-4E2-25 A110-4ME2-25 A113-4ME2-25	1 (P)	Female thread	Rc1/8
	4 (A), 2 (B)		
	3 (R2), 5 (R1)		
	PR	Female thread	M5×0.8

Notes: 1. The delivery port is the 2(A) for 111E1, A111E1-25.

2. Since 110E1 is for manifold use only, piping to the 1 (P) port with a fitting is not possible.

3. Not available in 110-4E2, 113-4E2, 110-4KE2, and 113-4KE2.

Manifold Connection Port Size

Manifold model	Port	Location of piping ports	Port size
111M□ ^F ^{Note1} 110M□ ^F	1 (P)	Manifold	Rc1/8
	4 (A), 2 (B)	Valve	M5×0.8 ^{Note2}
	3 (R), 3 (R2), 5 (R1)	Manifold	Rc1/8
110M□ ^{FE}	1 (P)	Manifold	Rc1/8
	4 (A), 2 (B)	Valve	M5×0.8
	3 (R2), 5 (R1)	Manifold	Rc1/8
	PR		M5×0.8
111M□ ^A ^{Note1} 110M□ ^A	1 (P)	Manifold	Rc1/8
	4 (A), 2 (B)		Rc1/8 (111M□ ^A), Rc1/4 (110M□ ^A)
	3 (R), 3, 5 (R)		
	PR		M5×0.8
111M□ ^{AJ} ^{Note1} 110M□ ^{AJ}	1 (P)	Manifold	Rc1/8
	4 (A), 2 (B)		Quick fitting for φ 4 or φ 6
	3 (R), 3, 5 (R)		
	PR		Rc1/8 (111M□ ^{AJ}), Rc1/4 (110M□ ^{AJ})
			M5×0.8

Notes: 1. The delivery port is the 2(A) for 111M□^F, 111M□^A, 111M□^{AJ}.

2. When the mounting valve is a female thread specification, the ports are this size. For the built-in quick fitting types, quick fittings for φ 4 or φ 6 are installed.

Solenoid Valve Mass

g [oz.]

Basic model	Mass
111E1	75 [2.65]
(110E1)	80 [2.82]
110-4E1	80 [2.82]
110-4E2	125 [4.41]
110-4KE2	175 [6.17]
113-4E2	145 [5.11]
113-4KE2	165 [5.82]
A111E1	80 [2.82] (180 [6.35])
(A110E1)	85 [3.00]
A110-4E1	85 [3.00] (180 [6.35])
A110-4E2	130 [4.59] (225 [7.94])
A110-4KE2	180 [6.35]
A110-4ME2	110 [3.88] (205 [7.23])
A113-4E2	150 [5.29] (245 [8.64])
A113-4KE2	170 [6.00]
A113-4ME2	120 [4.23] (215 [7.58])

Remark: Figures in parentheses () are the mass with sub-base-25


Manifold Mass

g [oz.]

Manifold model	Mass calculation of each unit (n=number of units)	Block-off plate
111M□ ^F	(15×n)+30 [(0.53×n)+1.06]	5 [0.18]
111M□ ^A	(45×n)+45 [(1.59×n)+1.59]	10 [0.35]
111M□ ^{AJ}	-J4 : (53×n)+45 [(1.87×n)+1.59] -J6 : (50×n)+45 [(1.76×n)+1.59]	
110M□ ^F	(20×n)+30 [(0.71×n)+1.06]	6 [0.21]
110M□ ^{FE}	(40×n)+50 [(1.41×n)+1.76]	11 [0.39]
110M□ ^A	(60×n)+60 [(2.12×n)+2.12]	
110M□ ^{AJ}	-J4 : (67×n)+60 [(2.36×n)+2.12] -J6 : (64×n)+60 [(2.26×n)+2.12]	

Cylinder Operating Speed

How to obtain cylinder speed




To obtain the time required for the cylinder to complete 1 stroke, add cylinder's delay time t_1 (time between energizing of solenoid valve and actual starting of the cylinder), to the cylinder's max. speed operating time t_2 .

When a cushion is used, add the cushioning time t_3 to the above calculation. The standard cushioning time t_3 is approximately 0.2 seconds.


110-4E1 113-4E2

● Measurement conditions

- Air pressure : 0.5MPa [5.1kgf/cm²] [73psi.]
- Piping inner diameter and length : ϕ 2.5 [0.10in.] $\times$ 1000mm [39in.]
- Fitting : Quick fitting TS4-M5
- Load ratio = $\frac{\text{Load}}{\text{Cylinder theoretical thrust}} (\%)$
- Cylinder stroke : 150mm [5.91in.]




Maximum operating speed



1mm/s = 0.0394in./sec.


Delay time




A110-4E1-25 A113-4E2-25

● Measurement conditions

- Air pressure : 0.5MPa [5.1kgf/cm²] [73psi.]
- Piping inner diameter and length : ϕ 4 [0.16in.] $\times$ 1000mm [39in.]
- Fitting : Quick fitting TS6-01
- Load ratio = $\frac{\text{Load}}{\text{Cylinder theoretical thrust}} (\%)$
- Cylinder stroke : 150mm [5.91in.]




Maximum operating speed



1mm/s = 0.0394in./sec.


Delay time




A110-4ME2 A113-4ME2

● Measurement conditions

- Air pressure : 0.5MPa [5.1kgf/cm²] [73psi.]
- Piping inner diameter and length : ϕ 4 [0.16in.] $\times$ 1000mm [39in.]
- Fitting : Quick fitting TS4-01
- Load ratio = $\frac{\text{Load}}{\text{Cylinder theoretical thrust}} (\%)$
- Cylinder stroke : 150mm [5.91in.]




Maximum operating speed






1mm/s = 0.0394in./sec.

Delay time



Flow Rate



How to read the graph

When the supply pressure is 0.5MPa [73psi.] and the flow rate is 180 l/min [6.35ft³/min.] (ANR), the valve outlet pressure becomes 0.4MPa [58psi.].

1MPa = 145psi.

1 l/min = 0.0353ft³/min.

110 Series Solenoid Valve, Air-piloted Valve Order Codes

2-, 3-port valve		2-, 3-port valve		3-position valve		Sub-base		Port fitting specifications		Manual override		Wiring type	
Number of ports		Valve function		Valve function				Note 2					
3-port		Normally closed (NC)		Closed center		Without sub-base				Non-locking type		Grommet type	
	Blank		Blank		Blank			Blank					
2-port		Normally open (NO)		Exhaust center		With sub-base				Locking protruding type		Straight connector with LED indicator	
	-2		-11		-13			-25					
				Pressure center								L connector with LED indicator	
					-14								

Notes : 1. They cannot be used as single units.

2. The port fittings are for φ 4: TSK4-M8M, and for φ 6: TSK6-M8M.

Notes : 3. Side mounting of valve is not possible when ~J41, ~J42, ~J43, ~J61, ~J62, or ~J63 is selected, because in these cases there are no mounting holes on the valve side surface.

4. Mounting on the manifold only is possible when ~J42 or ~J62 is selected for the 110-4E2 or 113-4E2, because in these cases they do not have mounting holes.


Additional Parts (To be ordered separately)

Speed controller



● For direct piping ● For sub-base piping

Muffler



● For direct piping ● For sub-base piping

Mounting base



● For direct piping
● For 2-, 3-port and 5-port single solenoids

Block-off plate



● M ● BP
111 — For 111M
110 — For 110M
F — For F type manifold
FE — For FE type manifold
A — For A type, AJ type manifolds

110 Series Manifold Order Codes

2-, 3-port valve
Number of ports

3-port

Blank

2-port

-2

2-, 3-port valve
Valve function

Normally closed (NC)

Blank

Normally open (NO)

-11

3-position valve
Valve function

Closed center

Blank

Exhaust center

-13

Pressure center

-14

Port fitting
specifications Note 2

Female thread : Blank

~J41, ~J42 : Quick fitting for ϕ 4 tube

~J61, ~J62 : Quick fitting for ϕ 6 tube

~J41

~J42

● 2(A) port of 111E1 (4(A) port of 110E1)

~J42

● 4(A), 2(B) ports of 5-port

~J62

Manual override

Non-locking type

Blank

Locking protruding type

-83

Wiring type

● Lead wire length: 300mm [11.8in.] is standard.

Grommet type

Blank

Straight connector with LED indicator

-PSL

L connector with LED indicator

-PLL

Straight connector with LED indicator

-CPSL

L connector with LED indicator

-CPLL

● -CP□L : DC12V and DC24V positive side, and AC100V, AC200V.

● -CM□L : DC12V and DC24V negative side.

Manifold
Connection port

Quick fittings for ϕ 4 tube

-J4

Quick fittings for ϕ 6 tube

-J6

	Manifold model Number of units		Station	Basic model						Voltage				
Manifold for 2-, 3-port valves	111M	2 ⋮ 20	F	stn. ☐	-111E1	-2	-11	-J41 -J61	-83	-PSL -PLL -CPSL -CMSL -CPLL -CMLL	-J4 -J6	DC12V DC24V AC100V AC200V		
			A AJ	stn. ☐	-A111E1	-2	-11							
Manifold for combination mounting of 2-, 3-, 5-port valves	110M	2 ⋮ 20	F FE ^{Note1}	stn. ☐	-110E1	-2	-11	-J41 -J61	-83	-PSL -PLL -CPSL -CMSL -CPLL -CMLL		DC12V DC24V AC100V AC200V		
				stn. ☐	-110-4E1			-J42 -J62						
				stn. ☐	-110-4E2									
				stn. ☐	-110-4KE2									
				stn. ☐	-113-4E2		-13 -14							
			stn. ☐	-113-4KE2										
			A AJ	stn. ☐	-A110E1	-2	-11	-83	-PSL -PLL -CPSL -CMSL -CPLL -CMLL	-J4 -J6	DC12V DC24V AC100V AC200V			
				stn. ☐	-A110-4E1									
				stn. ☐	-A110-4E2									
				stn. ☐	-A110-4KE2									
stn. ☐	-A113-4E2			-13 -14										
stn. ☐	-A113-4KE2													
Manifold for mount- ing 5-port valve (made to order)	110M	2 ⋮ 20	F	stn. ☐	-110-4A			-J42 -J62						
				stn. ☐	-110-4A2									
			A AJ	stn. ☐	-A110-4A					-J4 -J6				
				stn. ☐	-A110-4A2									

- Valve mounting location from the left-hand side when facing the 4(A), 2(B) ports.
- Since a twin solenoid valve requires 2 stations per valve to mount, the second station (solenoid 12(S1) side) should be blank.
- Notes : 1. Since the PR port on the port fitting type valves is located on the opposite side from the manifold, pilot air is exhausted directly from the valve. For that reason, collective exhaust is not possible and the port fitting type valves cannot be used for the manifold.
- 2. Fitting used for port fitting specifications, ϕ 4: TSK-M8M, ϕ 6: TSK6-M8M.
- Specify the valve model for each station.
- Enter -BP when closing a station with a block-off plate without mounting a valve.
- Specify only for F type manifolds.
- For the AJ type manifold only, specify either of the two.
- It is not required when ordering a single valve unit.
- Pre-wired common terminal for AC100V and AV200V is either -CPSL or -CPLL.

Made to Order The 110 series includes made to order items of various kinds for further system development. For details, see p.315~317.

Straight connector with LED indicator

-PSLN

● Without lead wire

● Connector, contacts included.

L connector with LED indicator

-PLLN

● Without lead wire

● Connector, contacts included.

Lead wire length

-1L
-3L

● For plug connector

● Length (mm)

-1L : 1000 [39in.]

-3L : 3000 [118in.]

DIN connector

-39

● Cannot be used with -L.

LED indicator with built-in varistor

-L

● Cannot be used with -39.

Built-in interface unit

-FA

● Possible to be directly controlled by output from micro computer or other logic devices.

● With LED indicator


Air-piloted valves 110 series

● 5-port, 2-position


● Single pilot

● Double pilot


3-port



111E1




111E1-11




Major Parts and Materials

	Parts	Materials
Valve	Body	Aluminum alloy (anodized)
	Stem	Aluminum alloy (anodized)
	Lip seal	Synthetic rubber
	Flapper	Synthetic rubber
	Mounting base	Mild steel (zinc plated)
	Sub-base	Aluminum alloy (anodized)
	Plunger	Magnetic stainless steel
Manifold	Column	Magnetic stainless steel
	Body	Aluminum alloy (anodized)
	Block-off plate	Mild steel (nickel plated)
	Seal	Synthetic rubber


5-port, 2-position




110-4E1
De-energized



110-4E2




110-4KE2




5-port, 3-position


Closed center



113-4E2




113-4KE2




Dimensions of Solenoid Valve, 2-, 3-port (mm)

111E1



A111E1-25



Additional Parts (To be ordered separately)

● Mounting base : 110-21



110-BASE

● Muffler




110-MUFF

● Speed controller



110-SC







For direct piping : KM-05

For sub-base piping : KM-11


For direct piping : SCE-M5

For sub-base piping : SCE-01




For options and made to order, see p.306.

Exhaust center



Pressure center







113-4E2-13

113-4KE2-13

113-4E2-14

113-4KE2-14





Dimensions of Solenoid Valve 5-port , 2-, 3-position (mm)


110-4E1



110-4E1




◀Viewed from A▶



A110-4E1-25




A110-4E1



110-4E2




110-4E2



A110-4E2-25




A110-4E2



113-4E2




113-4E2



A113-4E2-25



A113-4E2



Additional Parts (To be ordered separately)

● Mounting base : **110-21**  **110-BASE**

● Muffler  **110-MUFF**






● Speed controller  **110-SC**

For direct piping : **KM-05**

For sub-base piping : **KM-11**

For direct piping : **SCE-M5**

For sub-base piping : **SCE-01**



Options

● With quick fittings (2-, 3-port):


-J41 (For φ 4 tube, 2(A) or 4(A) port with fitting)

-J42 (For φ 4 tube, 1(P), 2(A) ports with fittings)

-J61 (For φ 6 tube, 2(A) or 4(A) port with fitting)


-J62 (For φ 6 tube, 1(P), 2(A) ports with fittings)

The drawing shows the -J42 specification.




● Locking protruding type manual override : **-83**

 **110-ROCK**



● Solenoid with straight connector : **-PSL**

 **110-PSL**



Note : PR is on the side with the A port.

● With quick fittings (5-port):


-J42 (For φ 4 tube, 4(A), 2(B) ports with fittings)

-J43 (For φ 4 tube, 1(P), 4(A), 2(B) ports with fittings)

-J62 (For φ 6 tube, 4(A), 2(B) ports with fittings)


-J63 (For φ 6 tube, 1(P), 4(A), 2(B) ports with fittings)

The drawing shows the -J43 specification.



● Solenoid with L connector : **-PLL**

 **110-PLL**



Note : PR is on the side with the A, B ports.

Remark: Valves with quick fittings do not have 2-φ 3.2 side mounting holes. Moreover, the quick fittings are the following types:

TSK4-M8M (for φ 4 tube), **TSK6-M8M** (for φ 6 tube)


mm

Model	Code	A	B	C	D	D'	ℓ (lead wire length)	Remarks
111E1, A111E1-25		82.5	75.5	90.6	77	77.2	-PSL, -PLL : 300 Made to order -1L : 1000 -3L : 3000	Overall length to the end of the valve or sub-base
110-4E1		88.5	81.5	96.6	83	83.2		
A110-4E1-25		94.5	87.5	102.6	89	89.2		
110-4E2, A110-4E2-25		134	120	150.2	123	123.4		Overall length to the end of the opposite side solenoid
113-4E2, A113-4E2-25		146	132	162.2	135	135.4		


Made to Order

 **110-PSL**


● Solenoid with DIN connector : **-39**




● Solenoid with LED indicator : **-L**




● Built-in interface unit : **-FA**



A110-4ME2-25-PSL





A110-4ME2-25-PLL




Options

● Locking protruding type: -83


● Locking manual lever type: -84



A113-4ME2-25-PSL





A113-4ME2-25-PLL



Options

● Locking protruding type : -83

● Locking manual lever type : -84




Dimensions of Manifold for 2-, 3-port Valves (mm)

111M ☐ F


Unit dimensions

Model	L	P
111M2F	48	41
3F	64	57
4F	80	73
5F	96	89
6F	112	105
7F	128	121
8F	144	137
9F	160	153
10F	176	169
11F	192	185
12F	208	201
13F	224	217
14F	240	233
15F	256	249
16F	272	265
17F	288	281
18F	304	297
19F	320	313
20F	336	329

111M ☐ A

Unit dimensions

Model	L	P
11M2A	48	41
3A	64	57
4A	80	73
5A	96	89
6A	112	105
7A	128	121
8A	144	137
9A	160	153
10A	176	169
11A	192	185
12A	208	201
13A	224	217
14A	240	233
15A	256	249
16A	272	265
17A	288	281
18A	304	297
19A	320	313
20A	336	329



SOLENOID VALVES 110 SERIES

 110-PSL ☐

-



TSK4-M8M (for $\phi 4$ tube), **TSK6-M8M** (for $\phi 6$ tube)

-PSL, -PLL : 300
Made to order **-1L : 1000, -3L : 3000**

Dimensions of Manifold for Combination Mounting of 2-, 3-, 5-port Valves (mm)

110M□F


CAD 110M-F



Unit dimensions



Model	L	P
110M2F	48	41
3F	64	57
4F	80	73
5F	96	89
6F	112	105
7F	128	121
8F	144	137
9F	160	153
10F	176	169
11F	192	185
12F	208	201
13F	224	217
14F	240	233
15F	256	249
16F	272	265
17F	288	281
18F	304	297
19F	320	313
20F	336	329

Example of combination mounting with twin solenoid valves



110M□FE

CAD 110M-FE




Unit dimensions

Model	L	P
110M2FE	48	41
3FE	64	57
4FE	80	73
5FE	96	89
6FE	112	105
7FE	128	121
8FE	144	137
9FE	160	153
10FE	176	169
11FE	192	185
12FE	208	201
13FE	224	217
14FE	240	233
15FE	256	249
16FE	272	265
17FE	288	281
18FE	304	297
19FE	320	313
20FE	336	329

110M□A

CAD 110M-A




Unit dimensions

Model	L	P
110M2A	48	41
3A	64	57
4A	80	73
5A	96	89
6A	112	105
7A	128	121
8A	144	137
9A	160	153
10A	176	169
11A	192	185
12A	208	201
13A	224	217
14A	240	233
15A	256	249
16A	272	265
17A	288	281
18A	304	297
19A	320	313
20A	336	329

SOLENOID VALVES 110 SERIES

110M□AJ


CAD 110M-A



Unit dimensions


Model	L	P
110M2AJ	48	41
3AJ	64	57
4AJ	80	73
5AJ	96	89
6AJ	112	105
7AJ	128	121
8AJ	144	137
9AJ	160	153
10AJ	176	169
11AJ	192	185
12AJ	208	201
13AJ	224	217
14AJ	240	233
15AJ	256	249
16AJ	272	265
17AJ	288	281
18AJ	304	297
19AJ	320	313
20AJ	336	329

For options and made to order, see p.310.

110M ☐ A

Unit dimensions

Model	L	P
110M2A	48	41
3A	64	57
4A	80	73
5A	96	89
6A	112	105
7A	128	121
8A	144	137
9A	160	153
10A	176	169
11A	192	185
12A	208	201
13A	224	217
14A	240	233
15A	256	249
16A	272	265
17A	288	281
18A	304	297
19A	320	313
20A	336	329

110M ☐ AJ

Unit dimensions

Model	L	P
110M2AJ	48	41
3AJ	64	57
4AJ	80	73
5AJ	96	89
6AJ	112	105
7AJ	128	121
8AJ	144	137
9AJ	160	153
10AJ	176	169
11AJ	192	185
12AJ	208	201
13AJ	224	217
14AJ	240	233
15AJ	256	249
16AJ	272	265
17AJ	288	281
18AJ	304	297
19AJ	320	313
20AJ	336	329

Made to Order

The 110 series Solenoid Valves include a variety of made to order solenoids for application in a wider range of control and wiring types.

Plug connector

Straight connector
with LED indicator



- Without lead wire
- Connector and contacts included


L connector
with LED indicator



- Without lead wire
- Connector and contacts included

- When ordering, enter **-PSLN** or **-PSLL** in place of the normal option code for the wiring type.

Lead wire length



- For plug connector
- Length mm [in.]
- 1L : 1000 [39]
- 3L : 3000 [118]

- For lead wire length, **-1L** is 1000mm [39in.] and **-3L** is 3000mm [118in.].
When ordering, enter **-1L** or **-3L** following the wiring type option code.

DIN connector



A compact connector that is highly resistant to dust and water splashes.

Employs a self-stripping method that eliminates the need for de-sheathing the lead wire.


- When ordering, enter **-39** in place of the normal option code for the wiring type.
- A varistor for surge suppression is also equipped.
(For the AC100V and AC200V only. For DC12V and DC24V, a flywheel diode for surge suppression is installed as standard equipment.)
- LED indicator is not available.

Wiring Instructions

● Solenoid with DIN connector


When de-sheathing (only the outer sheath of the cable), pay attention to the lead wire direction. The cover will be easily mounted when the lead wire on the outer side of the terminal cover is set about 8mm [0.31in.] longer than the inner side.

Without stripping off the sheath, insert the lead until it contacts the lead wire stopper on the terminal body, and then place the contact from the upper side. Then use pliers to press the lead wire further to ensure that the contact is firmly touching the core wire.



Note: The appropriate tightening torque for the cover mounting screw is 29.4N·cm {3kgf·cm} [2.6in·lbf].

LED Indicator



The LED indicator for confirmation of operation is also available without a plug connector. This creates a clean monoblock look with a compact cover.

- When ordering, enter **-L** in place of the normal option code for the wiring type.
- A varistor for surge suppression is also equipped.
(For the AC100V and AC200V only. For the DC12V and DC24V, a flywheel diode for surge suppression is installed as standard equipment.)


Built-in Interface unit



Includes an interface unit with a photo transistor. Can be directly controlled by a microcomputer and logic chip, and is equipped with full electric noise countermeasures and LED indicators.

- When ordering, enter **-FA** in place of the normal option code for the wiring type.
- Cannot be ordered in combination with any other solenoid option.
- Rated voltages for the solenoid are AC100V and AC200V only.

Block diagram




The interface unit is a triac with a photo coupler. Applying DC5V to the input terminals when AC power is applied on the solenoid side causes the LED inside the unit to light up, turns on the triac, and energizes the solenoid. At this time, an LED indicator turns on.

When the input side voltage reaches 0V, the LED inside the unit shuts off, the triac is turned off, and the solenoid is de-energized. At this time, the LED indicator is turned off.


With a built-in zero-cross circuit, the zero-cross voltage is used to turn the power on, and the zero-cross current to turn it off.

Example of control circuits


1. Control by transistor



2. Control by TTL, IC




3. Control by relay contact



4. When input is not a DC5V power supply

Install resistance externally to drop the input voltage to 4~6V.



Example

$$R1 = \frac{Vp - V_{CE}}{18 \times 10^{-3}} (\Omega)$$

Vp [V]	R1
12	390 Ω 1/4W
24	1.0K Ω 1W

In the case of $V_{CE}=0$ [V]

Solenoid Specifications for Valve with Built-in Interface Unit

Item			Specifications			
Input side	Rated voltage		DC V		5	
	Voltage range		DC V		4~6	
	Current (when 5V DC is applied)		mA		18	
	Operating voltage		DC V		4 or below	
	Return voltage		DC V		0.8 or over	
	Color of lead wire		Red (+), Black (-)			
Solenoid side	Rated voltage		AC V		100	200
	Type		Shading type			
	Operating voltage range		AC V		90~125 (100 ⁺²⁵ ₋₁₀ %)	180~250 (200 ⁺²⁵ ₋₁₀ %)
	Current (when rated voltage is applied)	Frequency Hz	50	60	50	60
		Starting mA(r.m.s.)	36	32	18	16
		Energizing mA(r.m.s.)	24	20	12	10
	Leakage current	Frequency Hz	50	60	50	60
		Current mA(r.m.s.)	0.3	0.4	0.6	0.8
	Surge suppression (as standard)		Built-in varistor on solenoid side			
	Color of lead wire		Yellow		White	
Color of LED indicator (as standard)		Yellow		Green		
Voltage resistance			Min. AC1500V at input side and solenoid side			
Insulation resistance			MΩ	Between input side and solenoid side, and between whole terminals and body		Over 100
Zero-cross function			Available			
Wiring type and lead wire length			Grommet type: 300mm [11.8in.]			


Wiring instructions

Color of lead wire
Solenoid power supply AC100V: Yellow
Solenoid power supply AC200V: White

Color of lead wire
Input ⊖ DC0V: Black
Color of lead wire
Input ⊕ DC5V: Red



1. Separate the input side and solenoid side lead wires by color. Never apply AC power/6VDC or more to the input side.
2. Ensure that voltage ripple on the input side remains within the range shown below.



3. Even when a wrong polarity is applied to the input side, a built-in diode for protection against reverse polarity eliminates any worry about short circuiting. The valve will not operate, however.
4. A varistor and condenser are built-in in the solenoid power supply side, for protection circuit against external surge voltages. As a result, there is a 0.3mA leakage current in AC100V, and a 0.6mA leakage current in AC200V.
5. The operation and return times of the interface unit are 10ms or less with a 50Hz AC power supply, and 8ms or less with a 60Hz AC power supply.

Made to Order

Air-piloted valves 110 series

- The ideal air valve for master valves or pilot valves for total pneumatic control.



Effective Area

mm² [Cv]

Specifications		For direct piping, F type manifold	For sub-base, A, AJ type manifolds
Basic model		110-4A, 110-4A2	A110-4A, A110-4A2
Single valve		4.2 [0.23]	4.0 [0.22]
Built-in quick fitting for ϕ 4 tube	~J42 4(A), 2(B) ports with fittings	3.6 [0.20]	3.6 [0.20] (When mounted on the AJ type manifold with ~J4 specification)
	~J43 1(P), 4(A), 2(B) ports with fittings		—
Built-in quick fitting for ϕ 6 tube	~J62 4(A), 2(B) ports with fittings	—	4.0 [0.22] (When mounted on the AJ type manifold with ~J4 specification)
	~J63 1(P), 4(A), 2(B) ports with fittings	—	—
Remarks		● Attaching TS4-M5 to the 1(P), 4(A), 2(B) ports gives the value 1.8 [0.1]. ● On the F type manifold, attaching TS4-M5 to the 4(A), 2(B) ports gives the value 2.1 [0.12]. ● When large flow rates are required, we recommend the built-in quick fittings.	

Specifications

		For direct piping, F type manifold		For sub-base, A, AJ type manifolds	
		Single pilot	Double pilot	Single pilot	Double pilot
Item	Basic model	110-4A	110-4A2	A110-4A	A110-4A2
Media		Air			
Operation type		Air-piloted type			
Number of positions and ports		2 positions, 5 ports			
Effective area (Cv) mm ²		4.2 {0.23} Note 1			
Port size	Main	M5×0.8 Note 2		— Note 2	
	Pilot	M5×0.8			
Lubrication		Not required			
Operating pressure range	Main	0.15~0.7 {1.5~7.1} [22~102]	0~0.7 {0~7.1} [0~102]	0.15~0.7 {1.5~7.1} [22~102]	0~0.7 {0~7.1} [0~102]
MPa {kgf/cm ² } [psi]		See the table "Minimum Pilot Pressure"			
Proof pressure MPa {kgf/cm ² } [psi]		1.05 {10.7} [152]			
Operating temperature range (atmosphere and media) °C {°F}		5~60 [41~140]			
Shock resistance m/s ² {G}		1373.0 {140.0} (Axial direction 294.2 {30.0})			
Mounting direction		Any			
Maximum operating frequency Hz		5			
Mass	g {oz.}	40 [1.41]	45 [1.59]	45 [1.59] {140 [4.94]} Note 3	50 [1.76] {145 [5.11]} Note 3

Notes: 1. For details, see the effective area.

2. For details, see the port size.

3. Figures in parentheses () are the mass with sub-plate: -25.

※ For optional specifications and order codes, see p.301~302.

Port Size

Specifications	Port	For direct piping, F type manifold	For sub-base, A, AJ type manifolds	Remarks
		110-4A 110-4A2	A110-4A A110-4A2	
Female thread	1(P)	M5×0.8	—	Standard
	4(A), 2(B) 3(R2), 5(R1)			
Built-in quick fitting	~J42 1(P)	M5×0.8	—	● Straight type ● For ϕ 4 tube ● For both nylon tubes and urethane tubes
	~J42 4(A), 2(B) 3(R2), 5(R1)	Built-in quick fitting		
	~J43 1(P)	Built-in quick fitting		
	~J43 4(A), 2(B) 3(R2), 5(R1)	Built-in quick fitting		
Sub-base -25	1(P) 4(A), 2(B) 3(R2), 5(R1)	—	Rc1/8	● All ports sub-base piping
F type manifold	1(P)	Rc1/8	—	● 1(P), 3(R2), 5(R1) manifold, 4(A), 2(B) valve piping
	4(A), 2(B) 3(R2), 5(R1)	M5×0.8 or quick fitting		
A type manifold	1(P)	—	Rc1/8	● All ports manifold piping
	4(A), 2(B) 3, 5(R)		Rc1/4	
AJ type manifold	1(P)	—	Rc1/4	● All ports manifold piping ● 4(A), 2(B) ports ~J4 : For ϕ 4 tube ~J6 : For ϕ 6 tube
	4(A), 2(B)		Built-in quick fitting	
	~J4		Built-in quick fitting	
	~J6		Built-in quick fitting	

Manifold Specifications and Port Size

Manifold model	Specifications	Port	Port size
F type	P, R manifold piping A, B valve piping	1(P)	Rc1/8
		4(A), 2(B)	M5×0.8 or quick fitting (Valve order code: ~J42)
		3(R2), 5(R1)	Rc1/8
A type	All ports manifold piping	1(P)	Rc1/8
		4(A), 2(B)	Rc1/8
		3, 5(R)	Rc1/4
AJ type	A, B ports built-in quick fittings All ports manifold piping	1(P)	Rc1/8
		4(A), 2(B)	~J4 Quick fitting for ϕ 4 tube
		~J6	Quick fitting for ϕ 6 tube
		3, 5(R)	Rc1/4

※ For optional specifications and order codes, see p.302.

Manifold Mass

g [oz.]

Manifold model	Mass calculation of each unit (n=number of units)	Mounting valve			
		110-4A	110-4A2	A110-4A	A110-4A2
F type	(20×n)+30 [(0.71×n)+1.06]	40 [1.41]	45 [1.59]	—	—
A type	(60×n)+60 [(2.12×n)+2.12]	—	—	45 [1.59]	50 [1.76]
AJ type	~J4 (67×n)+60 [(2.36×n)+2.12]	—	—	45 [1.59]	50 [1.76]
	~J6 (64×n)+60 [(2.26×n)+2.12]	—	—	45 [1.59]	50 [1.76]

Calculation example: The mass of 110M 10F stn.1~5 110-4A, stn.6~10 110-4A2 becomes (20×10)+30+(40×5)+(45×5)=655g [23.10 oz.]

Minimum Pilot Pressure

MPa [kgf/cm²] [psi]

Main pressure	0.15 [1.5] [22]	0.3 [3.0] [44]	0.5 [5.1] [73]	0.7 [7.1] [102]
Model	110-4A	110-4A2	110-4A	110-4A2
	0.15 [1.5] [22]	0.25 [2.5] [36]	0.34 [3.5] [49]	0.45 [4.5] [65]
	0.08 [0.8] [12]	0.10 [1.0] [15]	0.12 [1.2] [17]	0.14 [1.4] [20]

Required Time for Switching

S


Model	Operation	Pilot line length L m [ft.]						Measurement circuit	Measurement conditions
		2 [6.6]	6 [19.7]	10 [32.8]	20 [65.6]	50 [163.9]	100 [327.8]		
110-4A	ON	0.06	0.14	0.26	0.63	2.30	6.54		● Pilot valve=050-4E1 (effective area 1.2mm² [Cv: 0.067]) ● Tube inner diameter = 4mm [0.16in.] ● Air pressure (both main and pilot)=0.5MPa [73psi.]
	OFF	0.12	0.33	0.67	1.65	6.30	19.50		
A110-4A2	ON	0.07	0.16	0.29	0.70	2.66	7.40		
	OFF	0.07	0.16	0.29	0.70	2.66	7.40		

Cylinder Operating Speed and Flow Rate


110-4A

● Measurement conditions

- Air pressure : 0.5MPa [5.1kgf/cm²] [73psi.]
- Piping inner diameter and length: ϕ 2.5 [0.10in.]X1000mm [39in.]
- Fitting : Quick fitting TS4-M5
- Load ratio = $\frac{\text{Load}}{\text{Cylinder theoretical thrust}}$ (%)
- Cylinder stroke: 150mm [5.91in.]




Maximum operating speed




A110-4A-25

● Measurement conditions


- Air pressure : 0.5MPa [5.1kgf/cm²] [73psi.]
- Piping inner diameter and length: ϕ 4 [0.16in.]X1000mm [39in.]
- Fitting : Quick fitting TS6-01
- Load ratio = $\frac{\text{Load}}{\text{Cylinder theoretical thrust}}$ (%)
- Cylinder stroke: 150mm [5.91in.]



Maximum operating speed



Flow rate




How to read the graph

When the supply pressure is 0.5MPa [73psi.] and the flow rate is 210 l/min [7.41ft³/min.] (ANR), the valve outlet pressure becomes 0.4 MPa [58psi.].

SOLENOID VALVES 110 SERIES

Operating Principles and Major Parts

5-port, 2-position




Major Parts and Materials


Parts	Materials
Body	Aluminum alloy
Stem	(anodized)
Lip seal	Synthetic rubber
Mounting base	Mild steel (zinc plated)
Sub-base	Aluminum alloy (anodized)

Dimensions of Air-piloted 5-port, 2-position Valve (mm)

110-4A




110-4A2



Options

● Mounting base : -21




● With quick fittings: -J42 (For φ4 tube, 4(A), 2(B) ports with fittings)

-J43 (For φ4 tube, 1(P), 4(A), 2(B) ports with fittings)


-J62 (For φ6 tube, 4(A), 2(B) ports with fittings)

-J63 (For φ6 tube, 1(P), 4(A), 2(B) ports with fittings)


The drawing shows the -J43 specification.



● Speed controller : -70




● Muffler : -75




Dimensions of Air-piloted 5-port, 2-position Valve (mm)

A110-4A




A110-4A2




Options

● Sub-base : -25



● Speed controller : -70



Handling Instructions and Precautions




Solenoid

Internal circuit

●DC12V, DC24V


Standard solenoid (Surge suppression)



(2) and (3) are for with DIN connector (Order code : -39).


Solenoid with LED indicator (Surge suppression)

Order code : -PSL, -PLL



●AC100V, AC200V


Standard solenoid (Surge suppression)



(2) and (3) are for with DIN connector (Order code : -39).


Solenoid with LED indicator (Surge suppression)

Order code : -PSL, -PLL



●DC24V

Tandem solenoid



- Cautions:**
1. Do not apply megger between the lead wires.
 2. The DC solenoid will not short circuit even if the wrong polarity is applied, but the valve will not operate.
 3. Leakage current inside the circuit could result in failure of the solenoid valve to return, or in other erratic operation. Always use it within the range of the allowable leakage current. If circuit conditions, etc. cause the leakage current to exceed the allowable leakage current, consult us.
 4. For double solenoid and twin solenoid, avoid energizing both solenoids simultaneously. The valve could fall into a neutral position.




Plug connector

Attaching and removing plug connector

Use fingers to insert the connector into the pin, push it in until the lever claw latches onto the protruded section of the connector housing, and complete the connection.


To remove the connector, squeeze the lever along with the connector, lift the lever claw up from the protruded section of the connector housing, and pull it out.



※Illustration shows the 110 series.

Crimping of connecting lead wire and contact

To crimp lead wires into contacts, strip off 4mm [0.16in.] of the insulation from the end of the lead wire, insert it into the contact, and crimp it. Be sure to avoid catching the insulation on the exposed wire crimping section.




- Cautions:**
1. Do not pull hard on the lead wire.
 2. Always use a dedicated tool for crimping of connecting lead wire and contact.
- Contact: Model 702062-2M
Manufactured by Sumiko Tech, Inc.
Crimping tool: Model F1-702062
Manufactured by Sumiko Tech, Inc.


Attaching and removing contact and connector

Insert the contact with a lead wire into a plug connector □ hole until the contact hook latches on the connector and is secured to the plug connector. Confirm that the lead wire cannot be easily pulled out.

To remove it, insert a tool with a fine tip (such as a small screwdriver) into the rectangular hole on the side of the plug connector to push up on the hook, and then pull out the lead wire.




- Cautions:**
1. Do not pull hard on the lead wire, it could result in defective contacts, breaking wires, etc.
 2. If the pin is bent, use a small screwdriver, etc. to gently straighten out the pin, and then complete the connection to the plug connector.



Common terminal pre-wired plug connector


1. Pre-wired common terminal at DC positive side or AC.

Order code With straight connector: -CPSL
With L connector: -CPLL



2. Pre-wired common terminal at DC negative side

Order code With straight connector: -CMSL
With L connector: -CMLL



- Cautions:**
1. The diagrams show the straight connector configuration. While the connector's orientation is different in the case of the L connector, in every case the first COM lead wire comes from the last station's mounted valve.
 2. Since the COM terminal is connected to a crossover terminal inside the connector housing, the connector cannot be switched between a positive common and a negative common by changing the connectors.




Manual override

Non-locking type

To operate the manual override, press it all the way down. The single solenoid valve works the same as when in the energized state as long as the manual override is pushed down, and returns to the normal position upon release.

For the double solenoid and twin solenoid valves, pressing the manual override on the 12(S1) side switches the 12(S1) to enter the energized position, and the unit remains in that state even after the manual override is released. To return it to the normal position, operate the manual override on the 14(S2) side. This is the same for the solenoid 14(S2).




※Illustration shows the 110 series.

Locking protruding type

Use a small screwdriver to turn the adjusting knob several times in the clockwise direction, and lock the manual override in place. When locked, turning the adjusting knob several times in the counterclockwise direction releases a spring on the manual override, returns it to the normal position, and releases the lock.

For the locking protruding type, when the adjusting knob is not turned, this type acts just like the non-locking type, like the valve is the energized position as long as the manual override is pushed down, and it returns to the normal position upon release.



※Illustration shows the 110 series.


- Cautions:**
1. The 110 series valves are internal pilot type solenoid valves. As a result, the manual override cannot switch the main valve without air supplied from the 1(P) port.
 2. Always release the lock of the locking type and locking protruding type manual override before commencing normal operation.
 3. Do not attempt to operate the manual override with a pin or other object having an extremely fine tip. It could damage the manual override button.
 4. Do not turn the adjusting knob more than needed. It could result in defective operation.



Manual override (Tandem solenoid)

Locking type


To lock the locking type manual override, use a small screwdriver to push down the manual override in all the way, then set the 0 position as the reference point and turn it in the clockwise direction as far as position A. This achieves the same conditions as when the 14(SA) side is energized, and the manual override is locked in place. For the 12(SB) side, turn it in the counterclockwise direction as far as position B. To release the lock, return the manual override to the 0 position. A spring mechanism returns the manual override to its normal position, and the lock is released. Care should be taken to avoid excessive turning of the manual override, which could damage it.




Locking protruding type, locking manual lever type

To lock the locking protruding type manual override or locking manual lever type, use either a small screwdriver or your fingertips to push the manual override button (manual lever) all the way down, then set the 0 position as the reference point and turn it in the clockwise direction as far as position A. This achieves the same conditions as when the 14(SA) side is energized, and the manual override button (manual lever) is locked in place. For the 12(SB) side, turn it in the counterclockwise direction as far as position B. To release the lock, return the manual override button (manual lever) to the 0 position. A spring mechanism returns the manual override button (manual lever) to its normal position, and the lock is released. Care should be taken to avoid excessive turning of the manual override button (manual lever), which could damage it.

Locking protruding type manual override



Locking manual lever type



- Cautions:**
1. The 110 series valves are internal pilot type solenoid valves. As a result, the manual override cannot switch the main valve without air supplied from the 1(P) port.
 2. Always release the lock of the locking protruding type manual override before commencing normal operation.
 3. Do not attempt to operate the manual override with a pin or other object having an extremely fine tip. It could damage the manual override button.
 4. Do not turn the adjusting knob more than needed. It could result in defective operation.

Mounting base 110-21

When installing a mounting base to the valve, always use the provided screws. The recommended tightening torque for the screws is $49\text{N}\cdot\text{cm}$ $\{5\text{kgf}\cdot\text{cm}\}$ $[4.3\text{in}\cdot\text{lbf}]$.

Mounting valves on manifold

When mounting valves on manifold, apply the recommended tightening torque of $39.2\text{N}\cdot\text{cm}$ $\{4\text{kgf}\cdot\text{cm}\}$ $[3.5\text{in}\cdot\text{lbf}]$ for the valve mounting screws.

Handling Instructions and Precautions (PC Board Manifold)




Solenoid

Circuit configurations


● For positive common type (standard)

Operation example




Correspondence to sequencer

Output module is negative common type.




● For negative common type (optional: -CM)

Operation example



Correspondence to sequencer

Output module is positive common type.




Plug connector

Attaching and removing plug connector



Use fingers to insert the connector into the pin, push it in until the lever claw latches onto the protruded section of the connector housing, and complete the connection.

To remove the connector, squeeze the lever along with the connector, lift the lever claw up from the protruded section of the connector housing, and pull it out.



- Cautions:**
1. Do not pull hard on the lead wire. It could result in defective contacts, breaking wires, etc.
 2. If the pin is bent, use a small screwdriver, etc. to gently straighten out the pin, and then complete the connection to the plug connector.

Connector for flat cable



Manifold

Print circuit board

Avoid using in the locations listed below, as it may result in deterioration of the print circuit board or a short circuit in the wiring. If use in such conditions is unavoidable, always provide a cover or other adequate protective measures.

1. Locations subject to high levels of dust or oil mists
2. Locations subject to salt, corrosive gases, or conductive particles
3. Locations directly subject to condensation, direct sunlight, or other weather effects


Combination mounting for different type of valves

In the 110 series manifold for combination mounting of 2-, 3-, 5-port, and the PC board manifold for combination mounting of 2-, 3-, 5-port, single solenoids can be mounted together with double solenoids, or with twin solenoids, and a total number of up to 8 or 16 solenoids can be mounted.


In this case, observe the following precautions:

1. Always use a block-off plate (-BP) to close the next right station (the side with the higher numbered station) of the double solenoid valve mounting station.
2. When using block-off plates (-BP) for some reason other than item 1, place them together on the higher numbered stations side.
3. Connector pin numbers are allocated to stations in order from the left end of the manifold. For a double solenoid mounting, the upper pins are allocated to 14(S2) and the lower ones to 12(S1), with the upper 14(S2) numbers being the smaller pin numbers. And for a twin solenoid mounting, the left side is allocated to 14(S2) and the right side allocated to 12(S1), with the left side 14(S2) numbers being the smaller pin numbers.

Example of 4 single solenoid valves and 2 double solenoid valves installation on an 8 unit manifold:




Connector pin location of 8 units:



Remark: The standard is positive common wiring. Negative common wiring is optional (-CM).

Example of 3 single solenoid valves and 2 double solenoid valves installation on an 8 unit manifold:



Connector pin location of 8 units:



Remark: The standard is positive common wiring. Negative common wiring is optional (-CM).